


REQUEST TOOLS AT WWW.HTIGLOBAL.US





204/205/212

Main Rotor Trunnion Pillow Block Removal
HTI001

204/205/212

Main Rotor Yoke
Inner Race / Shield Removal
HTI002




204/205/212

Main Rotor Pitch Horn Removal
HTI003

212/412

Main Rotor Mast Inner Race Removal Tool
HTI004




212/412

Tail Rotor Trunnion
Inner Race Removal and Install
HTI005

212/412



Tail Rotor Trunnion Bearing Puller
HTI006






212/412
Main Hydraulic Servo Alignment Tools
HTI007

412
Collective lever Pin Removal Tool
HTI008



204/205/212
Collective Sleeve Holding Tool
HTI009

204/205/212/412
Outer Flex Coupling -604 Holding Tool
HTI010



212/412
Tail Rotor Hub Trunnion Centering Tool
HTI011


204/205/212/412
Swashplate Gimbal Ring Bolt Removal Tool
HTI012






412
HP/EP Tail Rotor
Output Adapter Backlash
WA
HTI013

212/412
90° Gearbox Holding Fixture
HTI014



AN Stud Installation Kit (3 Each)
HTI015


Rosan Serrated Lock Ring Cutting Tool Set
(4 Each)
HTI016



Garlock Seal Removal Kit
(3 Each)
HTI017


206B/206L
Component Work Aids
HTI018





206B/206L
Tail Rotor Hub and Blade Kit
HTI019

Main Rotor Trunnion
Inner Race Removal Work Aid
HTI020




206B/206L
Planetary Support
WA
HTI021

Bell 407 Tail Rotor Gearbox Wrench
HTI022



206B/206L
T/R G/BOX Nut NAS1493-7
HTI023

Allison/Rolls Royce 206/407 Hoisting Tool
PN# 6889888
HTI024



407 Component Work Aids HTI025

